

INSTRUCTIONS FOR USE

What you should pay attention to before first use of the appliance

MARMOTHERM heating panels are made of natural material – MARBLE or GRANITE. They have a high and economical heating capacity and have an aesthetic and noble appearance, which visually enhances every room.

Fine hairline cracks can appear on the plate due to temperature fluctuations. These affect neither the heating characteristics nor the appearance nor the quality of the panel itself.

MARMOTERM heating panels do not require any special maintenance. A damp cloth is sufficient for cleaning.

The room temperature is easily regulated by a thermostat.

BEFORE THE FIRST USE

Please note the following procedure before the first use:

1. Heat panel **for 15 min** = switch on
2. Then leave **for 60 min** = switch off
3. Then wipe the MARMOTHERM heating panel with a damp cloth.
4. Repeat this power on/off process one more time

After that, the heating system is ready for normal use.

ECONOMICAL WORKING

Due to its own thermostat regulation for each MARMOTERM heating panel, our system achieves the best results compared to conventional heating systems. If you set the thermostat to the desired room temperature, the MARMOTERM heating panel will only consume the required electricity. Once it has reached the desired temperature, its storage function comes into effect and the thermostat interrupts the power supply, since the MARMOTERM heating plate works like an electric tiled stove. When switched on 24 hours a day, you get an optimal balance between power consumption and pleasant warmth.

SAFETY MEASURES

The safety of the MARMOTERM heating plate is in accordance with all recognized technical regulations and safety rules of electrical devices.

1. Connect the MARMOTERM heating panel to a 240 V 50/60 Hz mains supply via a room thermostat using a 2-pin mains plug.
2. If the MARMOTERM heating panel is damaged, e.g. if the panel breaks, the panel is no longer usable.
3. The MARMOTERM heating panel must be at least 15 cm away from other objects in the room (furniture, curtains, etc.).
4. The MARMOTERM heating panel must not be mounted directly below a wall socket (heat generation).
5. The installation of heating panel in the bathroom or next to shower stalls must be carried out in such a way that the heating panel, the thermostat, the plug and the cable are protected from

direct contact with water. MARMOTERM heating panels and thermostats used in bathrooms must be installed out of the reach of people who are in the bath or shower.

6. No wet objects are to be placed on the heated MARMOTERM heating panel.
7. The MARMOTERM heating panel must be fixed to the wall with the help of supporting elements supplied by the manufacturer. The installation and commissioning of MARMOTERM heating panels can be carried out by any electrical company.
8. In order to avoid overheating of the heater, the MARMOTERM heating panel must not be covered with clothing or the like during operation, nor should any objects be leaned against the plate.
9. The MARMOTERM heating panel must not be mechanically damaged (by hard objects). It is shock-sensitive; it must not be sanded down, etc. No liquids or chemicals must be emptied over the MARMOTERM heating panel.
10. This heater is not to be used in the immediate vicinity of a bathtub, a shower or a swimming pool.
11. If the line is damaged, the device must be scrapped.
12. If the heater is connected directly to the fixed electrical installation without a connector plug, an all-pole disconnecting device with an opening width corresponding to the conditions of overvoltage category III must be installed for full isolation in accordance with the installation regulations
13. This device can be used by children aged 8 years or above, as well as by persons with reduced physical, sensory or mental abilities or lack of experience and knowledge, if they are supervised or have been instructed on the safe use of the device and understand the resulting dangers. Children are not allowed to play with the device. Cleaning and user maintenance must not be carried out by children without supervision.
14. Children younger than 3 years of age are to be kept away unless they are under constant supervision.
15. Children aged from 3 to 8 years may only turn the device on and off if they are supervised or have been instructed in the safe use of the device and have understood the resulting hazards, provided that the device is placed or installed in its normal position of use. Children from 3 to 8 years are not allowed to put the plug into the socket, regulate the device, clean the device and/or perform user maintenance.
16. **CAUTION!** Parts of the product may get very hot and cause burns. Special care should be taken when children and vulnerable persons are present.
17. No mounting in a wardrobe, on the ceiling or under benches is permitted

DISPOSAL NOTE:



Dispose of the device in an environmentally friendly manner if you want to dispose it. The device does not belong in the household waste. Dispose of it at a public collection point

WARRANTY POLICY

Thank you for purchasing our product and congratulations on this forward-looking decision. We are convinced that you have made a good choice with the purchase of MARMOTHERM heating panels, be it because of the clean handling, the completely silent heating option, the ideal room climate or because of the contribution to a clean environment.

The WARRANTY guarantees a free repair within 10 years from the date of purchase, exclusively for defects based on faulty materials or workmanship.

In case of damage, you have the following warranty claims:

- If the MARMOTEM heating panel cannot be repaired, the panel will be replaced by a new one. The warranty expires or MARMOTEM is not obliged to eliminate damage and technical defects free of charge caused by:
 - improper or careless use or installation (see assembly instructions)
 - improper connection or an unstable mains voltage
 - repairs, modifications or replacement of individual parts.